



## SPEware uSPE (ultraSPE) Faster / Cleaner Sample Preparation

### Steroids from Urine

For LC-MS or GC-MS confirmations using:  
Trace-N 35mg.

#### 1. APPLY SAMPLE

Add 2ml of sample to Trace-N column at a flow rate of 1-2ml/minute

#### 2. WASH COLUMN (All wash steps flow at 1-2ml/min)

1 x 1ml 5% Methanol with 2% Ammonium Hydroxide

1 x 1ml 45% Methanol with 2% Ammonium Hydroxide

#### 3. ELUTE DRUGS

1 x 1ml 70% Methanol with 2% Acetic Acid