
7694E Back Cover

	Description	HP Part No.	Qty
1	Main, switch	485-047-HSP	1
2	Plate, back	301-118-HSP	1
3	PC board—220 V, or	415-318-HSP	1
	PC board—115 V, or	415-319-HSP	
	Rebuilt PC board—220 V, or	415-322-HSP	
	Rebuilt PC board—115 V	415-323-HSP	
4	Main, fuses holder	485-048-HSP	1
	Fuses: 6A, F6 and switch module	445-072-HSP	2
	3A, Switch module only	445-069-HSP	2
5	Screen, power supply	301-189-HSP	1
Associated screws, washers, nuts, and spacers			
A	Screw, M3 X 10 flat head	0515-1005	2
B	Spacer, Nylon 10 X 4.5 X 4	301-105-HSP	4
C	Spacer, Nylon 10 X 6 X 4		4
D	Washer, toothed D4	2190-0640	8
E	Nut, M4	0535-0006	4
G	Screw, M4 X 12 pan head	0515-0909	4
H	Washer, toothed D5	2190-0641	4
J	Nut, M5	0535-0005	4




Figure 1-3. The Back Cover