

## 18587A/G1296A

The following is a list of replaceable parts for the HP 18587A/  
G1296A Bar Code Reader accessory:

---

<b>Description</b>	<b>New Part No.</b>	<b>Exchange Part No.</b>
BCR control board	18594-60100	18594-69100
BCR read head/cable	18587-60500	G1296-69500
18-volt jumper	18594-60670	
TEST VIAL	18587-60540	

---